



Wirelessly display, log, and transfer readings

Sper Scientific's Bluetooth® Sound Meter is small, light, and simple to use with results clearly displayed on the meter's large 1-½" backlit display. Choose A or C decibel frequency weighting scales and manual or auto ranging. Indicates readings over or under range and features minimum and maximum hold (peak) and data hold functions. The meter offers the convenience of Bluetooth® for wireless communication with free iOS app and coming soon to Android smart phone. Results can also be remotely viewed on your smartphone in real time, saved and exported. This enables the meter to be used as a remote wireless probe and as a datalogger. Comes ready to use with a windscreen, tripod screw, instructions and a 9V battery. N.I.S.T. traceable certificate of calibration available.

new



No.	Description	Each
850019	Bluetooth® Sound Meter	\$103.00
850019C	Bluetooth® Sound Meter Certified	\$136.00
840093	Field Tripod	\$35.00

File Name	Unit	Max	Min	Avg	Note	
7/7/2020 12:15	dB(A)	59	45.2	50.7286		
		50	50	50		
Sample	Date	Time	Unit(dBA)	Unit()	Unit()	Unit()
1	7/7/2020	12:15:30	55.4	50-100		
2	7/7/2020	12:15:31	48.3	50-100		
3	7/7/2020	12:15:32	46	50-100		
4	7/7/2020	12:15:33	45.2	50-100		
5	7/7/2020	12:15:34	45.5	50-100		
6	7/7/2020	12:15:35	59	50-100		
7	7/7/2020	12:15:36	55.7	50-100		



	Range	Resolution	Accuracy
	35 to 130 dB	0.1 dB	±1.5 dB @ 94 dB, 1kHz
Dimensions	7 ¼" x 2" x 1 ½" (185 x 54 x 36 mm)		
Weight	6.5 oz (184 g)		

