

# Lovibond® Water Testing Tintometer® Group



## SD 90 Salt



- Portable Hand-Held Meter
- Scroll-Through Functionality
- Compact & Robust
- Storage Function

Part Number: 194804-16

The SD series comprises a range of compact, easy-to-use, hand-held instruments for the accurate measurement of pH, ORP, Con, TDS or Salt. With robust housing and fully waterproof (IP67) casing, these testers are the ideal solution for in-situ testing in environmental, industrial or pool & spa applications.

The intuitive scroll-bar functionality and backlit display enable the easy measurement and simultaneous display of result, temperature, date/time and other measurement details. With 25 sets of data storage, each with date and time stamp, the units also enable the easy recalling of data for record keeping requirements. Designed and manufactured according to Lovibond® quality standards, the devices are equipped with replaceable electrodes to ensure long-life functionality in the field.

### Industry

Chemical Industry | Food and Beverage Industry | Industries Others | Marine Industry | Municipalities | NGO | Oil and Gas | Pharmaceutical Industry | Pool Public | Pool Services

### SD 90 Salt

The SD series comprises a range of compact, easy-to-use, hand-held instruments for the accurate measurement of pH, ORP, Con, TDS or Salt. With robust housing and fully waterproof (IP67) casing, these testers are the ideal solution for in-situ testing in environmental, industrial or pool & spa applications.

The intuitive scroll-bar functionality and backlit display enable the easy measurement and simultaneous display of result, temperature, date/time and other measurement details. With 25 sets of data storage, each with date and time stamp, the units also enable the easy recalling of data for record keeping requirements. Designed and manufactured according to Lovibond® quality standards, the devices are equipped with replaceable electrodes to ensure long-life functionality in the field.

### Measuring Range

Test Name	Measuring Range
Salinity	0 - 2 %

## Technical Data

<b>Measuring Range</b>	0 - 60°, < 20,00 ppt equal to 2,00 %
<b>Accuracy</b>	± 3 % FS
<b>Display</b>	22 x 22 mm LCD screen, yellow/green backlit
<b>Calibration</b>	up to 2 points calibration manual mode ± 50 % adjustable value
<b>Internal Storage</b>	25 sets of data storage, with date and time (non-volatile)
<b>Power Supply</b>	2 AAA batteries
<b>Battery Life Time</b>	> 350 hours (continuous use, backlight off), low battery indicator on LCD screen
<b>Clock</b>	Real Time Clock and Date
<b>Portability</b>	Portable
<b>Resolution</b>	0.01 % (when set to "P" % unit) ; 1 ppm (< 2000 ppm) ; 0.01 ppt (2.0 - 20.00 ppt)
<b>Resolution Temperature</b>	0.1 °C; Accuracy: ± 1 °C,selectable °C / °F system
<b>Compliance</b>	CE
<b>Dimensions</b>	1.73 x 1.3 x 8.07"

## Accessories

Title	Part Number
Replacement electrode for SD 70 Con, SD 80 TDS, SD 90 Salt	194822
Micro batteries (AAA), set of 4	1950026
Calibration solution salt-NaCl, 5.00 ppth	467621
Calibration solution salt-NaCl, 1000 ppm	467631

## Delivery Scope

- Meter in a robust plastic case with hanger
- 2 Batteries
- Lanyard
- Instruction Manual

**Tintometer GmbH**  
Lovibond® Water Testing  
Schleefstraße 8-12  
44287 Dortmund  
Tel.: +49 (0)231/94510-0  
sales@lovibond.com  
www.lovibond.com  
Germany

**The Tintometer Limited**  
Lovibond House  
Sun Rise Way  
Amesbury, SP4 7GR  
Tel.: +44 (0)1980 664800  
Fax: +44 (0)1980 625412  
sales@lovibond.uk  
www.lovibond.com  
UK

**Tintometer China**  
Room 1001, China Life Tower  
16 Chaoyangmenwai Avenue,  
Beijing, 100020  
Tel.: +86 10 85251111 App. 330  
Fax: +86 10 85251001  
chinaoffice@tintometer.com  
www.lovibond.com  
China

**Tintometer South East Asia**  
Unit B-3-12, BBT One Boulevard,  
Lebuh Nilam 2, Bandar Bukit Tinggi,  
Klang, 41200, Selangor D.E  
Tel.: +60 (0)3 3325 2285/6  
Fax: +60 (0)3 3325 2287  
lovibond.asia@tintometer.com  
www.lovibond.com  
Malaysia

**Tintometer Brazil**  
Caixa Postal: 271  
CEP: 13201-970  
Jundiaí – SP  
Tel.: +55 (11) 3230-6410  
sales@tintometer.com.br  
www.lovibond.com.br  
Brazil

**Tintometer Inc.**  
6456 Parkland Drive  
Sarasota, FL 34243  
Tel: 941.756.6410  
Fax: 941.727.9654  
sales@lovibond.us  
www.lovibond.com  
USA

**Tintometer India Pvt. Ltd.**  
Door No: 7-2-C-14, 2<sup>nd</sup>, 3<sup>rd</sup> & 4<sup>th</sup> Floor  
Sanathnagar Industrial Estate,  
Hyderabad, 500018  
Telangana  
Tel: +91 (0) 40 23883300  
Toll Free: 1 800 599 3891/ 3892  
indiaoffice@lovibond.in  
www.lovibondwater.in  
India

**Tintometer Spain**  
Postbox: 24047  
08080 Barcelona  
Tel.: +34 661 606 770  
sales@tintometer.es  
www.lovibond.com  
Spain

Technical changes without notice  
Printed in Germany

Lovibond® and Tintometer® are Trademarks of the Tintometer Group of Companies