



With a striking design and simple operation, the dual-range Raven scale is ideal for retail weighing and price computing. Front and rear backlit displays are visible by both operator and customer, allowing price and quantity verification. The Raven's easy-to-use keypad is sealed to keep out dirt, while its large stainless steel pan removes easily to enable quick cleaning between sales. For fast configuration and easy operation, the Raven contains 40 direct PLU keys. Suitable for use at outdoor stands or farmers' markets, the included rechargeable battery provides several days of work from a single charge. Adjustable feet can be locked to help stabilize the unit on busy countertops. The Raven is NTEP approved.

Price computing and weighing functions with 40 PLU memory locations



NTEP Type Approved



Features

- Backlit LCD shows weight, unit price and total price, to provide all key information simultaneously
- Color-coded keys facilitate quick recognition of the most frequently used buttons
- Lightweight design simplifies transport and portability
- Large, grade 304 stainless steel pan allows swift cleaning
- Overload protection helps prevent damage to internal components
- Solid ABS housing is durable for industrial uses
- Adjustable, non-slip feet can be locked to ensure balance is level
- Product Look Up (PLU) memory locations store a range of items for recall as needed
- Quick and easy configuration using the keypad
- Low-battery indicator alerts users when batteries need replacement
- Available in multiple currencies
- EC type and OIML approved
- AC adapter included
- Rechargeable battery included for operation almost anywhere

Applications

- Weighing
- Price computing



Rear View

About ADAM:

For 50 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Model	RAV 6Da	RAV 15Da	RAV 30Da	RAV 60Da
Capacity	3Lb / 6lb - 1.5kg / 3kg	6lb / 15lb - 3kg / 6kg	15lb / 30lb - 6kg / 15kg	30lb / 60lb - 15kg / 30kg
Readability	0.001lb / 0.002lb - 0.5g / 1g	0.002lb / 0.005lb - 1g / 2g	0.005lb / 0.01lb - 2g / 5g	0.01lb / 0.02lb - 5g / 10g
Pan Size	8.7"x12.2" / 220x310mm			
Weighing Units	lb:oz			
Stabilization Time (sec)	1			
PLU Memories	20 keys, 40 PLU			
Calibration	External calibration			
Display	Backlit LCD with 0.7" / 18mm-high digits			
Power Supply	12VDC 1A adapter / Internal rechargeable battery			
Operating Temperature	-10° to 40°C / 14° to 104°F			
Housing	ABS plastic			
Overall Dim.	13"x13.2"x4.5" / 330x335x115mm (wxdxh)			
Net Weight	8.5lb / 3.85kg			
Approvals	NTEP Approval			

Accessories

Item number	Description
700230020	In-use wet cover
700230021.....	In-use wet cover (pack of 5)
700230022.....	In-use wet cover (pack of 10)
303149761	Fish Scoop (complete with fitting to scales)
303149759	Vegetable Scoop (complete with fitting to scales)
303149760	Confectionery Scoop (complete with fitting to scales)

Key Accessories



Scoops
Metal scoops are designed to make portioning and food measurement easy. Three sizes available, small, medium and large.



In-use Cover
In-use covers provide an easy and affordable way to help keep the balance clean and protected.

Supplied by