



AELP pallet beams provide an affordable solution to weigh oversized or bulky items. Equipped with rugged built-in wheels and handles, AELP pallet beams are easy to set up and move. The low-profile beams permit easy accessibility to simplify loading, weighing and unloading. AELP comes with a 15-foot/5-meter shielded cable, allowing the indicator and beams to be positioned as needed. Four OIML-approved load cells provide precise, consistent measurements. The AELP pairs well with Adam's GK or AE 403 indicators.

## Low-profile beams facilitate safe, secure weighing of loaded pallets



### Features

- Low-profile beams allow easy pallet weighing using pallet trucks
- Approximately five-meter/15-foot shielded cable
- Heavy-duty rubber feet ensure stability of unit
- Integrated wheels permit easy movement
- Can be used with any Adam indicators
- Two beams per set

### Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Check counting
- Dynamic / animal weighing



AE 403 Indicator



GKa Indicator

### About ADAM:

For more than 45 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Model	AELP 1000	AELP 2000	AELP 3000	AELP 1000 [GKa]	AELP 2000 [GKa]	AELP 3000 [GKa]	AELP 1000 [AE403]	AELP 2000 [AE403]	AELP 3000 [AE403]
<b>Capacity</b>	2200lb / 1000kg	4400lb / 2000kg	6600lb / 3000kg	2200lb / 1000kg	4400lb / 2000kg	6600lb / 3000kg	2200lb / 1000kg	4400lb / 2000kg	6600lb / 3000kg
<b>Readability</b>	0.5lb / 0.2kg	1lb / 0.5kg	2lb / 1kg	0.5lb / 0.2kg	1lb / 0.5kg	2lb / 1kg	0.5lb / 0.2kg	1lb / 0.5kg	2lb / 1kg
<b>Repeatability (S.D.)</b>	1lb / 0.2kg	2lb / 0.5kg	4lb / 1kg	1lb / 0.2kg	2lb / 0.5kg	4lb / 1kg	1lb / 0.2kg	2lb / 0.5kg	4lb / 1kg
<b>Linearity (+/-)</b>	1lb / 0.4kg	2lb / 1kg	2lb / 1kg	1lb / 0.4kg	2lb / 1kg	2lb / 1kg	1lb / 0.4kg	2lb / 1kg	2lb / 1kg
<b>Excitation Voltage</b>	5 - 10 VAC / DC								
<b>Loadcells</b>	4								
<b>Pan Size</b>	4.7"x52.4" / 120x1330mm								
<b>Weighing Units</b>	N/A			kg, lb, lb:oz, oz, N			g, kg, lb, lb:oz, oz, N, custom unit		
<b>Stabilization Time (sec)</b>	2			2					
<b>Interface</b>	N/A			RS-232					
<b>Calibration</b>	External calibration			External calibration					
<b>Display</b>	N/A			Backlit LCD with 0.8"/ 20mm -high digits					
<b>Power Supply</b>	N/A			12VDC 800mA adapter / Internal rechargeable battery					
<b>Operating Temperature</b>	-10° to 40°C / 14° to 104°F								
<b>Housing</b>	Mild steel base								
<b>Cable Length</b>	16' / 5M								
<b>Overall Dim.</b>	4.7"x52.4"x3.3" / 120x1330x85mm (wxdxh)								
<b>Net Weight</b>	74.9lb / 34kg			79.3lb / 36kg			79.3lb / 36kg		

## Accessories

Item number	Description
3052010526	In-use wet cover - GKa Indicator only
3074010266	RS-232 cable (null-modem) - GKa Indicator only
700400103	RS-232 cable - AE 403 Indicator only
3074010507	RS-232 to USB adapter (must order corresponding RS-232 cable)
1120014641	AIP impact printer
1120011156	ATP thermal printer
600002028	AdamDU Data Collection Program
2050013351	Indicator stand
700660289	Calibration certificate

### Key Accessories



**ATP thermal printer**  
Easy-to-use features combined with quick set-up equals a truly versatile thermal printer. A single push-button feed key and three easy-to-read LED indicators make operation simple.



**AdamDU data collection program**  
Adam DU software connects a balance to the laboratory network, helping to achieve seamless data collection, transfer and analysis. DU features an easy-to-use interface with a main command window, allowing users to quickly collect information from up to eight Adam balances simultaneously using RS-232 or USB connections.

### Supplied by