



## INJECTION EXTENSION



The injection extensions are essential accessories for the dosing of a product directly in the pipeline.

They are particularly useful for the injection of chlorine, as they reduce the risk of blockages due to the crystallization of the product, also preventing the corrosion of the sleeve on which is screwed the injection valve.

The STEIEL injection extension features an adjustable insertion depth, for injecting the product at the center of pipes of different sizes.

Furthermore, this pull-out model allows to perform the maintenance and replacement of the injection valve even with piping under pressure.

### DATI TECNICI

Materials	PVC body, FPM gaskets
Working Temperature	max 45 °C
Working pressure	max 6 bar
Length	max 250 mm
Installation	½" GAS connections
Valve	½" ball valve

**Part No.** 97009015

